





CROSSBLADES - Innovation for snowshoers

A novel snowshoe system that allows you ascending, downhill skiing and gliding has recently conquered the market: Crossblades are a high-tech innovation, developed in Switzerland.

Quickly and easily, this new type of snowshoe ski can be switched from climbing to skiing and vice versa. This makes it possible to alternately ascend and glide down hills and fields on hikes without having to mount, remove, unpack and pack skins or other accessories. The learning curve is minimal, even for non-skiers starting out on gentle terrain.







Ascending Skiing Gliding







Functionality of the swivel plate

The waisted, glass fibre reinforced swivel plates consist of a ski base with steel edges on one side and a permanently integrated high-performance climbing skin on the reverse side.

After loosening the buckle at the rear end of the Crossblades, the swivel plate can be pushed to the side, turned by 180° and latched again.

Two magnets in the middle of the plate centre and fix the swivel plate to the top deck. This ensures perfect gliding even on flat terrain and effortless climbing even on hard surfaces. The ski base can be machine

sanded and waxed.

Twin-Deck principle

The Twin-Deck principle has a double function: it forms a narrow surface for traversing hardsnow slopes, which makes it easier to edge up and enables effortless swinging downhill. In deep snow, on the other hand, the upper deck widens the wing considerably.



Crossblades are available with soft boot bindings for mountaineering boots, hiking boots, trekking shoes and soft boots, or with hard boot bindings for skiing and touring boots.



Crossblades with Softboot binding

Crossblades with Hardboot binding





Dimensions and weights

- Length and width of the Crossblades: 89 cm and 19.5 cm respectively (no safety binding required)
- Weight of Crossblades with softboot binding: 4320 gr per pair
- Weight of Crossblades with hardboot binding: 3720 gr per pair
- Adjustable for shoe sizes 36 46

Accessories





Crossblades bag

Official Prices:

- Crossblades with Softboot binding (for hiking and mountain boot) € 459
- Crossblades witht Hardboot binding (for ski boots) € 429
- Bag: € 58
- Crampons: € 59

Crossblades Online presence

Visit our websites/shops:

Switzerland: www.crossblades.ch
International: www.crossblades.com

Manual and video: https://www.crossblades.com/en/tips-and-tricks

Follow-us on the social media platforms:

Instagram: #swisscrossblades https://www.instagram.com/swisscrossblades/

Facebook: https://www.facebook.com/swisscrossblades/

Others: YouTube, TikTok